

# mont·bell

## 取扱説明書

# サイクルロック マウント

### Bicycle Lock Mount

この度はお買いあげいただき、誠にありがとうございます。この取扱説明書（以下「本説明書」といいます）は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。


なお、ご不明な点等ございましたら、販売店もしくは(株)モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

## ■ 特長


ワンタッチでワイヤーロックを自転車のシートポストなどに取付できるようになるアタッチメントです。

## ■ 各部の名称

※取り付けに必要な4mm六角レンチは付属しません。



マウント本体



ホルダー



ラバーパッド



マウント用ボルト



ホルダー用ボルト

## ■ 安全上の注意

**必ずお読みください**

**危険** 人が死亡または重傷を負う危険が差し迫って生じることが想定される内容です。

- 亀裂などの損傷が生じた場合は直ちに使用を中止してください。
- 本製品は自転車用に設計されています。他の用途には使用しないでください。
- 取り付け後、タイヤへの干渉などにより運転に支障がないか必ず確認してください。

**注意** 人が傷害を負ったり物的損害の発生が想定される内容です。

- ロックをホイールやクランクの近くにぶら下げて走ると、絡まって転倒する恐れがあります。
- 自転車の形状によっては取付できない場合があります。
- 本製品の改造や分解は絶対にしないでください。
- 正しいお手入れ方法、保管方法を守ってお使いください。

## ■ 使用前の点検


使用にあたっては、毎回必ず次のことを確かめてください。異常が見られた場合は使用しないでください。

- 変形や亀裂等がないか
- ボルトに緩みがないか


## ■ 使用方法

ボルトの締め過ぎにご注意ください。製品が破損する恐れがあります。


### ○ マウント本体の取り付け



シートポスト  
またはフレーム  
ラバーパッド  
ベルト



マウント用ボルト




①ラバーパッドをマウント本体とシートポスト、またはフレームの間に挟み込み、ベルトをマウント本体に通します。


②マウント用ボルトをベルトの溝に合わせてマウント本体に挿入し、4mm六角レンチでマウントが固定されるまで締めこみます。

③余ったベルトをニッパーなどで切り落とします。


## ○ホルダーの取り付け



①ベルトをワイヤーロックに巻き付けホルダー本体に通します。




②ボルトを溝に合わせてホルダー本体に挿入し、4mm六角レンチでホルダー本体が固定されるまで締めこみます。




③余ったベルトをニッパーなどで切り落とします。

## ○ロックの取り付け



### ●ロックの取り付け

ホルダーをマウント本体の溝にカチッと音がするまで差し込みます。取り付け後、運転、走行に支障がないか必ず確認してください。



### ●ロックの取り外し

マウント本体側面のリリースボタンを押しながら、ホルダーを抜き取ります。

## ■お手入れ方法

間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。使用後や保管時は以下の点を参考にしてください。

○汚れがひどい場合はぬるま湯で洗い、十分に乾燥させてください。

## ■保管方法

○保管場所は雨や直射日光の当たらない風通しのいい場所を選んでください。

○本製品を火のそばや暖房器具のそばなどの高温になるところに置かないでください。変形や損傷の原因になります。

## ■廃棄方法

○廃棄方法はお住まいの自治体の収集方法に従ってください。

## ■アフターサービス

お買い求めいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡ください。

製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

○本製品の誤った使用方法によるもの ○間違ったお手入れ、保管方法、経年変化による素材劣化

○乱暴な取り扱いによるもの ○その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理させていただきます。

## ■仕様

品番：1130671

品名：サイクルロック マウント

素材：ナイロン

アタッチメント径：Φ22.5 ~ 34.9mm

対応ケーブル径：Φ6 ~ 15mm

## ■その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

# mont-bell User's Manual Bicycle Lock Mount

## Bicycle Lock Mount

Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product.


If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

### Description


Enables quick and easy attachment of a lock to the seatpost or other part of a bicycle.

### Components

\*The 4mm allen wrench required for installation is NOT included.



Mount



Holder



Rubber pad



Bolt for mount



Bolt for holder

### Safety Warnings

Please read carefully.



#### DANGER!

Under certain conditions, use of this product can result in major injury or death.

- Stop using this product immediately if you notice any cracks, damage or irregularities.
- This product is designed for cycling. Do NOT use this product for any other activity for which it is not designed.
- After installation, check for any interference with the tires that may affect cycling.



#### CAUTION!

Under certain conditions, use of this product can result in injury or property damage.

- Riding with a lock hanging close to the wheels or cranks may result in tangling, causing a fall.
- May not be compatible depending on the size and shape of the bicycle.
- Do NOT modify or alter this product. Improper modifications and alterations can damage the product and impair functionality.
- Please follow recommended care and storage instructions.


**Prior to use, inspect this product for:** Stop using immediately if you notice any irregularities.

- Cracks and deformation damage     Loose bolts


### Directions

Do NOT excessively tighten bolts. May damage the product.


#### Attaching the mount



- 1 Insert the rubber pad between the mount and the seatpost or frame, and pass the belt through the mount.




- 2 Insert the bolt for mount into the body of the mount while aligning it with the grooves in the belt, and tighten with a 4mm allen wrench until the mount is secure.




- 3 Cut off the excess belt with nippers or another cutting tool.


## ○ Attaching the holder



① Wrap the belt around the lock and pass it through the holder.




② Insert the bolt for holder into the body of the holder while aligning it with the grooves, and tighten with a 4mm allen wrench until the holder is secure.



③ Cut off the excess belt with nippers or another cutting tool.

## ○ Attaching a lock



● Attaching a lock  
Insert the holder into the groove in the mount until it clicks into place. After installing this product, always check that the product does not hinder riding abilities.



● Removing a lock  
While pressing the release button on the side of the mount, pull out the holder.

Release button

## ■ Care

Improper care and storage can shorten the lifespan of this product. To extend the lifespan of this product, please follow the recommendations below.

○ Wash away stains and soiling with lukewarm water. Allow to air dry in a cool, well-ventilated area.

## ■ Storage

○ Store in a well-ventilated, cool, dry place away from direct sunlight and rain.

○ To prevent deforming and damage, do NOT store near heat sources.

## ■ Disposal

○ Please follow local regulations regarding waste disposal.

## ■ Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at Montbell's discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

## ■ Specifications

Style# : 1130671

Name : Bicycle Lock Mount

Material : nylon

Attachment  $\varnothing$  : 22.5 ~ 34.9mm / 8.9 ~ 13.7in

Compatible cable  $\varnothing$  : 6 ~ 15mm / 2.4 ~ 5.9in

All product specifications and design are subject to change without prior notice. Actual product specifications may vary.

mont-bell Co.,Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN  
<https://www.montbell.com/>

44-5516-2402