

mont・bell

共通取扱説明書

# ドライ ストレージバッグ

Dry Storage Bag


この度はお買いあげいただき、誠にありがとうございます。この取扱説明書（以下「本説明書」といいます）は本製品の正しい取扱方法を説明しています。ご使用前に本説明書をよくお読みいただき、正しい使用方法をご確認ください。

なお、ご不明な点等ございましたら、販売店もしくは（株）モンベル カスタマー・サービスまでお問い合わせください。本説明書は大切に保管してください。

## ■ 特長

本製品は、ギアやウエアを湿気から保護し、加水分解などによる劣化を和らげる保管用バッグです。ストレージバッグは、酸素透過度の極めて低いフィルムとジッパーを使用。一般的なシリカゲルの約7倍の吸湿性をもつ乾燥剤と一緒に製品を入れて保管することで、加水分解のリスクを大幅に抑え、製品をより長くご使用していただけます。

## ■ 各部の名称



## ■ 安全上の注意

必ずお読みください

**警告** 場合により人が死亡または重傷を負う可能性が想定される内容です。軽傷または物的損害が発生する頻度が高いことが想定される内容です。

- ご使用前に、必ず点検してください。老朽化や、損傷がある場合は使用しないでください。
- 乾燥剤の薬剤が眼に入った場合は水で数分間注意深く洗ってください。コンタクトレンズを着用していて容易に外せる場合は外して洗浄してください。また、直ちに医師に相談してください。

**注意** 人が傷害を負ったり物的損害の発生が想定される内容です。

- 乾燥剤の薬剤を内袋から取り出さないでください。内袋が破れた場合、速やかに使用を中止してください。漏れた薬剤が衣類を汚したり、革製品を変質させる恐れがあります。
- 乾燥剤の内袋を汚したり、破いたり、圧迫しないでください。薬剤が漏れ出す恐れがあります。
- 本製品は食べられません。誤って口に入れた場合はすぐに吐き出し、うがいをしてください。誤って飲み込んでしまいが気分が悪くなった場合は、直ちに医師に相談してください。
- 誤って乾燥剤の薬剤を吸入した場合は、清潔な空気の下で呼吸しやすい体勢で休息してください。
- 乾燥剤の薬剤が皮膚や衣類などに付着した際は水でよく洗い流してください。
- 使用中にアレルギー症状等が発生した場合はただちに使用を中止して医師に相談してください。
- 子どもが近づかない場所で使用してください。薬剤の誤飲など、思わぬ事故の原因となる恐れがあります。
- 本来の用途以外に使用しないでください。
- ストレージバッグは排気ガスなどの影響で変色する場合がありますが、性能上の問題はありません。
- 正しいお手入れ方法、保管方法を守ってください。誤ったお手入れや保管方法を行うと、本来の性能を発揮できない恐れがあります。



## ■ 使用前の点検

使用にあたっては、毎回必ず次のことを確かめてください。異常が見られた場合は使用しないでください。


□ストレージバッグや乾燥剤の内袋に破れなどがないか

## ■ 使用方法

- ① 保管する製品をできるだけ乾燥させます。汚れがひどい場合は汚れを落としてから乾燥させてください。
- ② 乾燥剤を透明の外袋から取り出します。外袋を破る際は、中の乾燥剤を傷つけないように切り込みからやさしく破いて取り出してください。
- ③ 保管する製品と乾燥剤をストレージバッグに入れます。
- ④ 空気を抜きながら、力を入れ過ぎずにスライダーを動かしてジッパーを閉じます。



- ⑤ ジッパーに閉じていない箇所が無いが、指で触って確認してください。



- ※ 保管する製品を収納前にできるだけ乾燥させてください。濡れた製品と一緒に入れないでください。
- ※ 保管する製品のメンテナンス方法については、それぞれの取扱説明書またはウェブサイトをご覧ください。
- ※ 空気をできるだけ抜いてからジッパーを閉じてください。
- ※ スライダーは力を入れずに動かしてください。力を入れ過ぎるとフィルムやジッパーが破損する恐れがあります。
- ※ スライダーで口を閉じた後、ジッパーに閉じていない箇所が無いがよく確認してください。ジッパーが閉じていないと本製品の性能を発揮できません。
- ※ 外袋を開封すると直ちに除湿が始まります。使用直前までは外袋を開封しないでください。
- ※ 直射日光や紫外線の当たる場所、65℃を超える温度環境では使用しないでください。

### 乾燥剤の交換目安

開封してから1年間を目安にお取り換えください。吸湿が進むと薬剤がフレーク状から弾力のある手触りに変化します。保管する製品の状態や季節などによって、乾燥剤の有効な期間は異なります。交換する際は別売の「ドライ ストレージバッグ用 乾燥剤」をご使用ください。

## ■ お手入れ方法

間違ったお手入れ方法や保管方法は本製品の寿命を縮めます。使用後や保管時は以下の点を参考にしてください。

- 汚れたときは、良く絞った柔らかい布でふいてください。硬い布でふいたり、強くこすると、フィルムが破損する恐れがあります。また、70℃以上のお湯は使用しないでください。

## ■ 保管方法

- 風通しがよく、湿度が高くない場所で、直射日光を避けて保管してください。
- 保管時は刃物や鋭利な物と接触させないでください。
- 折り目がつかないように丸めて収納してください。きつく折り曲げるとフィルムやジッパーが破損する恐れがあります。

## ■ 廃棄方法

- 廃棄方法はお住まいの自治体の収集方法に従ってください。

## ■ アフターサービス

お買い求めいただきました本製品は万全を期して製造しておりますが、万一不備な点がございましたら、お買い求めいただいた販売店、もしくは下記の弊社窓口までご連絡ください。製造上の欠陥による不具合の場合は無償で交換させていただきます。なお、修理、交換等の要否につきましては、弊社の裁量にて判断させていただきます。

なお、以下のような原因での破損、不良につきましては保証いたしませんのでご了承ください。

- 本製品の誤った使用方法によるもの
- 間違ったお手入れ、保管方法、経年変化による素材劣化
- 乱暴な取り扱いによるもの
- その他、製造上の欠陥以外の原因によるもの

破損時は弊社にて診断をして、修理が可能な場合はご要望により有償にて修理させていただきます。

## ■ 仕様

品番：1134162 品名：ドライ ストレージバッグS  
：1134163 ：ドライ ストレージバッグM

素材：（ストレージバッグ）ナイロン、PET、ポリエチレン 乾燥剤の成分：塩化カルシウム、増粘剤

## ■ その他

本製品の仕様、デザインは予告なく変更されることがあります。また、重量などのスペックには誤差が生じる場合があります。

# mont·bell

## User's Manual

# Dry Storage Bag


### Dry Storage Bag

Thank you for purchasing this product. Before using, please carefully read this manual for instructions on the proper care and usage of this product. If you have any questions regarding this product, please contact Montbell Customer Service or the store of original purchase. Keep this manual for future reference.

## Description

This product helps keep your outdoor clothing and gear dry and protected from moisture while in storage to prevent gradual degradation and allow for long-lasting use. Utilizes a film with extremely low oxygen permeability, a zippered closure and a desiccant agent that is about 7 times more moisture absorbent than ordinary silica gel.

## Components



## Safety Warnings! Please read carefully.

**WARNING!** Under certain conditions, use of this product can result in injury, death, or property damage.

- Prior to use, check the product's condition and stop using immediately if you notice any damage or irregularities.
- If desiccant agent gets into the eyes, rinse thoroughly with water for several minutes. If you're wearing contact lenses that can be easily removed, remove them and then thoroughly rinse the eyes. Consult a physician immediately afterwards.

**CAUTION!** Under certain conditions, use of this product can result in injury or property damage.




- Do NOT remove desiccant agent from the desiccant pack. If the pack is torn, stop using immediately. Agent may leak and stain clothes or alter leather products.
- Do NOT soil, tear, or squeeze the desiccant pack. Doing so may cause desiccant agent to leak out.
- This product is NOT edible. If it accidentally enters the mouth, spit it out immediately and gargle water. If you accidentally swallow it and feel unwell, immediately consult a physician.
- If desiccant agent is accidentally inhaled, rest in a comfortable position and breathe in clean air.
- If desiccant agent gets on the skin or clothing, rinse thoroughly with water.
- Stop using immediately if you notice an allergic reaction.
- When using the product, place out of the reach of children. Failure to do so may result in accidents such as ingestion.
- Do NOT use this product for any other purpose for which it is not designed.
- Vehicle exhaust and other fumes may cause discoloration of the storage bag, but this has no effect on performance.
- Please follow proper care and storage instructions. Improper care and storage can lead to a decrease in performance.

**Prior to use, inspect this product for:** Stop using immediately if you notice any irregularities.

☐ **Tears in the storage bag or desiccant pack**

## Directions

- ① Before storing items in this product, dry them as much as possible. If items are heavily soiled, clean off dirt before drying.
- ② Remove the desiccant pack from the clear packaging. When opening the packaging, gently tear along the tear line so as not to damage the desiccant pack inside.
- ③ Place the desiccant pack and item(s) to be stored inside the storage bag.
- ④ While pushing out air, close the zipper by gently moving the slider.
- ⑤ Slide your fingers along the zipper to ensure the storage bag is completely sealed.



- ※ Before storing items in this product, dry them as much as possible. Do NOT store together with wet items.
- ※ Refer to the care and storage instructions in the user's manuals or websites of each item you are storing.
- ※ Remove as much air as possible before sealing the storage bag.
- ※ Gently move the slider when closing the zipper. Excessive force may damage this product's film or zipper.
- ※ After closing the slider, make sure the zipper on the storage bag is completely sealed. If the zipper is not completely sealed, the product will NOT perform as intended.
- ※ Desiccation begins as soon as the desiccant pack's packaging is opened. Do NOT open the packaging until immediately before use.
- ※ Do NOT leave this product in direct sunlight, exposed to ultraviolet rays, or in temperatures exceeding 65°C.

## Replacing the moisture absorber

Replace the moisture absorber within one year of opening the packaging. As moisture is absorbed, the desiccation agent will change from feeling flaky to elastic to the touch when it is felt through the desiccant pack. The effective period of usability will vary depending on the conditions and seasons this product is used in. Replace the moisture absorber with Dry Storage Bag Moisture Absorbers (sold separately).

**Care** Improper care and storage of this product can shorten its lifespan. Follow the recommendations below to extend the lifespan of your product.

- When soiled, gently wipe with a soft, damp cloth. Wiping with a hard cloth or rubbing with force may damage the film. Do NOT use water above 70°C to clean.

## Storage

- Store in a well-ventilated, cool, dry place away from direct sunlight.
- Keep this product away from knives and other sharp objects.
- When storing the product while not in use, roll up without creating folds or creases. Strong bending and folding may damage the film or zipper.

## Disposal

- Please follow local regulations regarding waste disposal.

## Warranty

Montbell's warranty covers all defects in materials and workmanship to the original owner, for the lifetime of the product. If a product ever fails due to a manufacturing defect, Montbell will repair or replace the product at Montbell's discretion. This warranty does not cover damage(s) caused by accident, improper care, negligence, misuse, alterations or normal wear and tear. Damage(s) not covered under warranty will be repaired at a reasonable rate. If you would like to make a warranty inquiry, please contact Montbell Customer Service or the store of original purchase.

## Specifications

Style# : 1134162 Name : Dry Storage Bag S  
: 1134163 : Dry Storage Bag M

Material: (Storage bag) nylon, PET, polyethylene (Desiccant agent) calcium chloride, thickener

All product specifications and design are subject to change without prior notice.  
Actual product specifications may vary.

mont·bell Co., Ltd.

2-2-2 Shinmachi, Nishi-ku, Osaka 550-0013 JAPAN  
<https://www.montbell.com/>